
Stage 1
Stage 2
Stage 3
Stage 4
Stage 5
Preload Adjuster compresses spring
Spring extends & reduces sag
Fitted Preload
Free Spring
L
X
Laden sag
Laden load (W)
Reduced Laden sag
(W)
No external load (wheel off ground)